PARTS LIST

for

KitchenAid®

UNDERCOUNTER DISHWASHER

MODEL

KUDA230YWH0

▲

▲ Wh−White,
AL−Almond

FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS

KITCHENAID ST. JOSEPH MICHIGAN 49085

10−92 Litho in U.S.A.
©1992 KITCHENAID
Part No. 4171700 Rev. A

DOOR AND PANEL PARTS

For Model: KUDA230YWH0



Illus. No.	Part No.	DESCRIPTION
1	4162215	Screw
2	9741100	Upper Mounting Panel Assembly (Includes Lower Trim)
3	4171421	Filler (Upper Panel)
4	4159439	Screw, 6 X 1/4
5	4171395	Side Trim (Upper Panel)
6	4171624	Side Trim (Lower Panel)
7	4162735	Grommet, Panel
8	4171623	Lower Mounting Panel Assembly (Includes Upper & Lower Trim)
9	4162734	Filler (Lower Panel)
10	4159494	Lock Washer
11	4159390	Screw, 10 X 1/2
12	4171625	Trim, Panel (Upper & Lower)
13	9740868	Channel, Evaporation
14		Panel Insert Kits
	4171595	White/Black
		OPTIONAL KITS
	4171592	Harvest Gold/ Almond
	4171200	Almond/White
	4171201	Harvest Gold/ Onyx Black
	4171198	Stainless Steel

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BLOWER PARTS

For Model: KUDA230YWH0



Illus. No.	Part No.	DESCRIPTION
1	9740633	Cover, Air Inlet
2	4161590	Float, Check Valve
3	9740634	Vent Tube
4	9740635	Seal
5	9740632	Retainer, Vent Tube
6	9740638	Dryer Housing
7	4162703	Bracket, Housing Support
8	4159442	Screw, 8−18 X 5/16 (8)
9	9740664	Screw (2)
10	4159178	Screw, 10−16 X 5/8 (2)
11	4162741	Wheel, Blower
14	4162443	Cover, Dryer Motor
15	4162742	Blower Motor Assembly
18	4162990	Clip, Thermoprotector
19	4160464	Thermostat
21	9740629	Heater, Open
22	4163186	Access Cover
23	9740631	Bracket, Blower Mounting

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: KUDA230YWH0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL PARTS

For Model: KUDA230YWH0

Illus. No.	Part No.	DESCRIPTION
1	9740861	Timer
2	9741312	Board, Light
3	4171236	Light Cover
4	4159432	Screw, Drive (2)
5	4171272	Spring, Switch
6	4171158	Barrier, Timer
7	4162214	Screw (4)
8	9741190	Switch, Program
9	4171253	Guide, Cancel Spring
10	9741052	Screw
11	4171255	Bracket, Interlock Switch
12	4171256	Spring, Interlock
13	4163602	Switch, Interlock
14	4171400	Bracket, Program Switch
15		Insert, Control Panel
	4171703	White
	4171704	Almond
	4171735	Black
	9741242	Brushed Chrome
16	9741310	Pushbutton (8)
17	4171381	Screw, 8 X 1/2
18	9740119	Insulator, Door Switch
19	4159364	Screw, 8 x 5/16
20	9740189	Lens, Light
25	4162043	Clip, Grounding
26	4159373	Screw, 8−18 X 1/2
30	4171364	Bracket, Door Panel
32	4171270	Handle, Latch
33	9741328	Screw, 10−32 x 5/8
34	4163372	Clip, Harness Guide
35	9741046	Wiring Harness (Main)
	4159349	Screw, 8−18 X 3/8
39		Control Panel (Includes 15 & 20)
	4171701	White
	4171702	Almond
	4163538	Pushnut, Membrane
40	4171351	Lead, Program Switch

LITERATURE AND OPTIONAL PARTS

LITERATURE PARTS

Part No.	DESCRIPTION
LIT9741183	Instructions, Installation
LIT9741382	Tag, Energy Fact
LIT9741221	Sheet, Tech (Service Information)
LIT9741182	Guide, Use & Care
LIT4171700	Parts List

ACCESSORIES

Part No.	DESCRIPTION
9741087	Drain Hose Assembly
4171476	Adjustable Kickboard Kit
4162841	Wood Top Kit

SIDE PANEL KITS

Part No.	DESCRIPTION
4171632	White (R.H.)
4171633	Almond (R.H.)
4171634	White (L.H.)
4171635	Almond (L.H.)

OPTIONAL PARTS NOT INCLUDED

PAINT, TOUCH−UP (1/2oz.)

Part No.	DESCRIPTION
72017	White
72107	Almond
72110	Golden Harvest
72112	Toast
72113	Platinum

PAINT, PRESSURIZED SPRAY (13 oz.)

Part No.	DESCRIPTION
350930	White
350956	Almond
261890	Golden Harvest
285006	Superior Black
285365	Toast
285366	Platinum
206922	Primer (White)
350941	Leveler (Thinner)

PAINT, BULK (1 qt.)

Part No.	DESCRIPTION
799344	White (Uncut)
978883	Almond (Uncut)
261891	Golden Harvest (Uncut)
285367	Toast (Uncut)
285368	Platinum (Uncut)

TUB LINER REPAIR

Part No.	DESCRIPTION
799832	Kit, Epoxy Patch (White)

DISHRACK REPAIR

Part No.	DESCRIPTION
675576	Vinyl Touch−Up (Blue)
675506	Tine Tip Repair Kit (Blue− Enough For Two Complete Dishracks)

INSULATION KIT

Part No.	DESCRIPTION
4171179	Insulation Kit (Kit Includes Tub, Kickboard, and Lower Panel Insulation)

PUMP AND MOTOR PARTS

For Model: KUDA230YWH0



PUMP AND MOTOR PARTS

For Model: KUDA230YWH0

Illus. No.	Part No.	DESCRIPTION
1	675704	Inlet Base Assy. (Also Order Item 30) See Note A.
2	675705	Impeller
3	9741232	Screw, 8−18 (16)
6	95080	"O" Ring
9	9740676	Box, Separator Collector (Also Order Item 30) See Note A.
10	9741258	Screw, 8−18 (4)
12	3371152	Screw & Seal, 10−32 x 3/4
13	9740677	Seal, Pump Outlet
14	9740683	Outlet, Pump (Includes Item 13)
15	3369482	Check Valve (Includes Item 6)
16	717000	Gasket, Pump
17	9740665	Pump & Motor Assembly (Includes Item 16)
18	302707	Bushing, Grind
19	302718	Chopper Kit (Also Order Item 30) See Note A.
20	302705	Sleeve, Drain Impeller
21	9741321	Screw, 8−18
22	302704	Seal, Drain Cover
23	302723	Cover, Drain (Also Order Item 30) See Note A.
24	303539	Impeller, Drain Kit (Also Order Item 30) See Note A.
25	9740671	Base, Pump (Includes Item 24) (Also Order Item 30) See Note A.
26	3367197	Support, Pump Mounting (4)
27	3368270	Slinger (See Note A.)
28	3369330	Motor (Includes Items 24 & 27) (Also Order Item 30) (For Electrical Connector Only, See Wiring Harness Page.) See Note A.
29	3369331	Screw (4)
30	675703	Pump Seal Kit (Includes Items 12, 13, 22, 33 & 36)
31	303918	Tool, Pump Centering
33	9740674	Gasket, Drain Cover
35	4161605	Connector, Overhead
36	9740678	Seal
39	9741366	Tube, Drain
40	370445	Clamp, Hose
41	9741415	Cap, Drain

Note A:
Pump Centering Tool Required For Pump Re−Assembling Order Item 31.

LOWER WASHARM AND STRAINER PARTS

For Model: KUDA230YWH0



Illus. No.	Part No.	DESCRIPTION
1	9740787	Wash Arm Assembly
3	9741049	Strainer (Coarse)

HEATER PARTS
For Model: KUDA230YWH0



Illus. No.	Part No.	DESCRIPTION
1	9740724	Element, Heater
2	4162521	Grommet, Heater Element
3	4163554	Washer, Heater Element
4	718537	Nut, Heater Element
6	4163522	Thermostat
7	9741277	Probe, Heat Sensing
8	4159822	"O" Ring
9	4161644	Gasket

FILL AND OVERFILL PARTS

For Model: KUDA230YWH0

Illus. No.	Part No.	DESCRIPTION
1	9740392	Hose, Flexible (Fill Valve to Air Gap)
2	4162103	Clamp, Hose
3	9740394	Air Gap, Fill Assembly (Includes Items 1 & 2)
4	4161545	Gasket, Rubber
5	4171300	Nut (Fill Air Gap)
6	4161505	Clamp, Hose
7	4171000	Fill Valve Assembly
8	9740980	Screw, 10−16 X 1/2
9	309330	Strap (Flexible Connector to Tank)
10	4159424	Screw, 4−40 X 3/4
11	9740811	Switch, Overfill Control
12	4161732	Standpipe, Overfill
13	4161670	Gasket, Flat
14	4161596	Nut, Standpipe
15	4171216	Float & Retainer Assembly
16	4171116	Lever, Overflow Switch



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER WASH AND RINSE PARTS

For Model: KUDA230YWH0



Illus. No.	Part No.	DESCRIPTION
1	9740307	Tube & Connector Assembly
2	9740763	Connector, Vertical Conduit
3	4162655	Conduit, Vertical
4	4162609	Retainer, Conduit
5	4171540	Retainer, Manifold
6	4171541	Manifold, Upper Arm
7	4161737	Screw
8	4162625	Bearing, Arm (Bottom)
9	4162491	Bearing, Arm (Top)
10	9740878	Wash/Rinse Arm Assembly
11	4171542	Clip, Wash Arm Guard (4)
12	4171551	Clip, Wash Arm Guard (4)
13	4161737	Screw
14	4171544	Tube (Manifold to Receiver)
15	4171543	Guard, Arm
16	4162624	Washer
17	4171545	Arm, Receiver

FRAME AND TANK PARTS

For Model: KUDA230YWH0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FRAME AND TANK PARTS

For Model: KUDA230YWH0

Illus. No.	Part No.	DESCRIPTION
1	4171627	Short Frame Assembly (Includes Items 2, 18, 19, 21 & 23)
2	9740980	Screw, 10−16 X 1/2
3	4161631	Door Seal Assembly (Includes Item 4)
4	4161608	Clip, Seal
5	4161626	Bumper, Door
7	9740303	Clip, Retainer
9	4171197	Actuator, Interlock Switch
10	4159115	Lock Nut
11	4160092	Keeper, Latch
12	4159421	Screw, 10−16 X 3/8
13	9741251	Bracket, Top Panel Anchor
14	9741257	Screw, 7−19 X 1/2
16	9741276	Support, Lower Panel
17	4162151	Screw, 10−32 X 1/2
18	4171620	Frame Assembly (L.H.)
19	9741173	Cross Frame, Rear
20	9740120	Sleeve, Actuator Spacer
21	4171619	Frame Assembly (R.H.)
22	4159443	Screw, 1/4−20 x 1/2
23	4161368	Cross Frame, Front
24	4171618	Kick Board
25	4162911	Foot, Leveling
26	4159494	Lock Washer
27	4159372	Screw, 10−32 X 3/8
28	4161369	Enclosure, Elec. Supply
	4159396	Screw, 8−18 X 1/2
29	4171176	Shield, Insulation
30		Trim, Tank
	4171304	R.H.
	4171305	L.H.
31	9741233	Screw, 10−24 X 1/2
32	9741374	Tank (Serviced Complete with Frame)
33	4171215	Protector, Edge
34	304658	Start Relay
35	4159403	Screw, 8−18 X 1−1/4
36	9741248	Spring Assembly (Heavy Duty)

UPPER RACK AND TRACK PARTS

For Model: KUDA230YWH0



Illus. No.	Part No.	DESCRIPTION
1	4171557	Upper Rack Assembly (Includes Item 2, 3, 4, 5 & 15)
	* 4171546	Complete Upper Rack Assembly (Includes Lower Sprayarm Parts)
2	4161226	Nut, Roller
3	4171288	Bearing & Spacer, Rack Roller
4	4162452	Washer
5	4159428	Screw, 10−16 X 1
6	4162442	Track, Rack
7	718829	Nut, Lock
8	9740023	Tip
9	9741062	Washer
10	718817	Washer, Cup
11	9740963	Roller, Rack Track
12	9740964	Screw, Track Roller
13	4171547	Bumper, Rack Track
14	4160423	Stud, Bumper Retaining
15	4162048	Bumper, Upper Rack
16		Track, Adjustable
	4171289	L.H.
	4171290	R.H.
17	4161607	Roller, Upper Track
18	4159593	Washer
19	4159283	Screw, 8−32 X 1/4 (4)
20		Lift, Receiver
	4171293	R.H.
	4171294	L.H.
21	4159428	Screw, 10 X 5/8
22	4171548	Partition
23	4160480	Clip, Partition (6)
24		Quadrant, Divider
	4171549	R.H.
	4171550	L.H.
26	4171551	Clip, Wash Arm Guard
27		Rackstop
	4171291	R.H.
	4171292	L.H.
28	4171491	Rivet

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER RACK PARTS

For Model: KUDA230YWH0



Illus. No.	Part No.	DESCRIPTION
1	9741002	Lower Rack Assembly (Includes Items 2, 3 & 5)
2	4162321	Axle, Lower Rack
3	4162322	Wheel, Lower Rack
4	4171553	Basket, Silverware
5	4171555	Bumper, Lower Rack
6	4171556	Plate Rack
7	4171554	Lid, Basket

DOOR AND LATCH PARTS

For Model: KUDA230YWH0



Illus. No.	Part No.	DESCRIPTION
1	4161659	Cover, Wiring Harness
2	4159513	Washer
3	3369139	Screw, 10−16 x 3/8
4	9740841	Latch Mechanism Assembly
5	4162145	Insulation, Switch
6	4171275	Inner Door Assembly
7	4163577	Insulation, Inner Door
8	9740922	Screw & Washer Assembly
9	4161592	Bracket, L.H. Door Stop
10	9740847	Plug Button
11	4160355	Bearing, Door Stop Insert (2)
12	4162949	Vapor Barrier, Inner Door (Includes Item 41)
13		Bracket, Spring Mounting
	4161958	R.H.
	4161957	L.H.
15	4159184	Screw, 10−32 X 3/8
16	4161594	Bracket, R.H. Door Stop
19	4161587	Bracket, R.H. Hinge
20	9740413	Spring, Door Co−Balance
21	4161563	Pin, Hinge
22	4161585	Clip, Hinge Pin Retaining
23	9740851	Screw
24	4171447	Seal, Detergent Dispenser
25	9741365	Screw, 8−18 X 1/2
26	4162568	Bimetal Assembly
27	4161295	Baffle, Lower
28	9741050	Screw, 8−18 X 1/2
30	9740171	Detergent Dispenser & Gasket Assembly (115 V., 60 Hz.) (Includes Item 24)
32	4159594	Washer (Rubber)
33	4162151	Screw, 10−32 X 1/2
34	4171221	Fill Hole Plug Assembly (Includes Item 35)
35	4162496	Washer, Fill Hole Plug
36	4171300	Nut, Rinse Agent Dispenser
37	4161545	Gasket, Rinse Agent Dispenser
38	9741234	Rinse Agent Dispensing Valve
39	4161589	Bracket, L.H. Hinge
41	4162950	Vapor Barrier, Corner (2)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST